

## Diesel Land Rover Pre-1983

### Instructions for changing Land Rover Hair Pin Series Wired Glow Plugs to Parallel Wired Probe Type Glow Plugs

- Remove existing wiring between ballast resistor and glow plugs also between glow plug and earth discard.
- Remove existing hair pin type glow plugs from engine and discard.
- Fit new probe type glow plugs to engine and tighten to recommended torque.
- Using the new wiring supplied, wire the glow plugs and ballast resistor. It is important that the terminal nuts are properly tightened.
- Start engine as usual.

